
Hinge along this vertical joint to allow the Aircraft to move offstage. 3'-4 1/2" 6'-8 1/2" 9'-3" Panel folds to rest against the scaffold frame. 2'-5" 1x4 Pine--3/4" Plywood Practical Door Opening-Performer Entrance Through Here Rolling Scaffold- 2 5'x7' sections with wheels. Attach scenery Flatage to scaffold tower. This shows the location.

Jet Aircraft Framing

Flat frame construction & ply panels covered with 1/4" sheetboard (luan, plywood or hardboard)

Cover with muslin as needed to provide a smooth surface.



Jet Plane Framing X of X

