



- Attach 2x4 to scaffold using Pipe straps and carriage bolts as shown. Place one that spans the plane above the door opening and two (or three) below the door opening. The pipe strap on the left is for EMT conduit and is located in the electrical section. The strap on the right is for steel plumbing pipe and is located in the plumbing section at Menards.
- Once you have horizontal 2x4 attached to the scaffold, screw through the 2x4 and into the 1x4 framing of the Jet scenery pieces with construction screws. I would drill pilot holes in the 2x4 for the screws .
- Additional vertical 2x4 might be added between the horizontal boards as needed for more attachment points to the 1x4 framing of the Jet.

Jet Aircraft Attachment to Scaffold