


ZOOM H2 Simple Recording Guide

1 Turn power to H2 on





Set [POWER] switch ON.

2 Press (REC) key to set H2 to recording mode



[PLAY/REC] indicator flashes red.

3 Adjust sensitivity with [MIC GAIN] switch





You can monitor the input level.

4 Press (REC) key once more to start recording




Now stays constantly lit red.

5 Press (REC) key to stop recording



Unit returns to the start of the recorded file.


6 Press (PLAY/PAUSE) key to play the recorded file





[PLAY/REC] indicator lits green.

Tips for Mic pattern setting

Switching mic pattern by object or situation is effective for your recording.




FRONT 90




For recording solo vocal or a musical instrument.

REAR 120



For stereo recording widely with room ambience.

SURROUND




For recording band rehearsal etc. It is possible to pick up the sound from front and rear side of H2 at once.

Use windscreen on mic of H2 when outdoor recording.



It can reduce wind hitting noise.

Return counter zero or select previous file. Fast-rewind by holding down.



Select next file. Fast-forward by holding down.